

**Door Activation Devices** 

# OE-ED2000 Universal Electric Strike

INSTALLATION INSTRUCTIONS



#### THIS PACKAGE INCLUDES:

- 1- 4 PIN power connector
- 2- #10 x 1 1/4" wood screws
- 2- #10-32 x 1/2" screws
- 2- Mounting brackets
- 2- Spacers

- 4- Wire nuts
- 5- M5 x 12mm screws

#### 1. DESCRIPTION

OE-ED2000 low profile grade 2 ANSI strike for cylindrical locksets offers the very best strike quality and performance, with three stainless steel faceplates provided. The 'Universal' strike design delivers unparalleled application flexibility, with field selectable voltage, fail safe/fail secure operation and mechanical adjustment of the strike body.


## 2. SPECIFICATIONS

Voltage	12/24V AC/DC
Current Draw	300mA@12V DC 150mA@24V DC
Static Strength	1,000 Lbs.
Dynamic Strength	50 Ft-Lbs.
Endurance	700,000 Cycles (Factory Tested) 250,000 Cycles (UL Verified)
Mode	Field Selectable Fail Safe/Fail Secure
Mech. Adjust- ment	Strike Body/Faceplate
Operation	AC-Buzz DC-Silent
Duty	Continuous
Dimensions (Body)	3 3/8" H x 1 7/8" W x 1 7/32" D (86mm x 47mm x 31mm)

#### **UL 294 Performance Levels**


- Line Security = Level I
- Attack Level = Level I
- Endurance Level = Level IV
- Standby Power = Level I

# 3. DIMENSIONS



#### 4. INSTALLATION

- 1. Prepare the door jamb as per the appropriate drawing.
- 2. Install mounting brackets to jamb using M5x12 screws and pressed metal nuts. Do not tighten.
- 3. Spacers are used to assure flush final assembly of faceplate into jamb. Add one of more spacers between jamb and mounting bracket when face plate extends beyond the jamb. When the faceplate sits inside the jamb, spacers must be added between the mounting bracket & the lip bracket. Make sure clearance hole in spacer aligns with hole in mounting bracket.




**Vertical Centerline** 

Note: The products are intended to be installed in accordance with the installation wiring diagram, mechanical assembly drawings provided with each product, the local authority having jurisdiction (AHJ) and the National Electric Code, NFPA 70. When installed in fail secure mode, the local authority shall be consulted with regard to the use of possible panic hardware to allow emergency exit from the secure area.

The electric door strike shall be installed in such a way and in such a location so as to not impair the operation of an emergency exit device or panic hardware mounted on the door.

- 4. Connect wires coming from the low voltage side of the transformer to wires (black) from strike.
- 5. Install electric strike jamb by attaching with # 10-32 screws and lockwashers.
- 6. Secure M5x12 screws holding mounting brackets to jamb.



#### 5. CONNECTIONS


POWER 24VDC 12VDC

Red/Black: +12V
Blue/Green: Ground

Red: +24V
Black/Blue: Green: Ground

A varistor is provided to protect/prevent strike from spikes. Connect varistor between input wires.


Note: For UL 294 / UL 1034 compliance the door strikes are to be powered via a UL 294 / UL 603 class 2 power limited output from a control panel and or power supply. Furthermore, when powered by AC/DC the units shall use a UL regulated UL 294 / UL 603 power limited class 2 output rated 12/24V with AC on indicator.




### 6. OPERATION

How to modify fail-safe to fail-secure or vice versa.

- (1) Loosen the Set Screw as per the diagram below.
- (2) Rotate the Mode Selector to the desired setting.
- (FL Fail-Secure, FS- Fail-Safe). The Set Screw will slide to its new position as the Mode Selector is rotated.
- (3) Tighten the Set screw.



Fail-Safe mode when Mode Selector is pointing to FS




Fail-Lock mode when Mode Selector is pointing to FL


Note: FS = Fail Safe FL = Fail Lock


## 7. FACEPLATES

#### **AVAILABLE FACEPLATES**



132mm 16mm 155mm 155mm 1,7 1,2 38 149mm 1,7 1,2 38 1,2 38 1,3 39mm 1,4 39mm 1,5 49mm 1,6 49mm 1,7 49mm 





**OE-EFS1 - ANSI SQUARE** 

**OE-EFS3 - WOOD DOOR** 

[173mm]

**OE-EFS4 - HOLLOW METAL DOOR** 

**OE-EFS2 - ANSI ROUND** 

CAMDEN Opening New Doors to
DOOR CONTROLS Innovation, Quality and Support!

Call: 1.877.226.3369 / 905.366.3377 Visit: www.camdencontrols.com



File: OE-ED2000\_Universal\_Strike\_ Manual.indd Revision: April 12th 2022 Part No: # 40-82B309